

FIG. 2




FIG. 3






FIG. 4








FIG. 6B




FIG. 7

		70A
REPRODUCTION		
	SLIDE	SHOW
		MENU
		SELECT "SLIDE SHOW" AND DEPRESS "MENU" BUTTON
		70B
SLIDE SHOW		
	REPEAT	ALL 3sec FORWARD DIRECTION OFF TART
		MENU

SELECT "START" AND DEPRESS "MENU" BUTTON, THEN SLIDE SHOW IS STARTED

FIG. 8

